

# **Deactivate the Rootkit**

Anibal Sacco Alfredo A. Ortega





#### **History:**

2004: The BIOS size of 60% of all notebooks suffered an increase of 25Kb

- Fast forward 5 years, 2009:
  - We were trying to install our own BIOS rootkit (Persistent BIOS Infection Talk, CanSecWest / Syscan)
  - We found that there was something already there!





#### What is the rootkit?

- Absolute Corp. Computrace, Anti-theft agent
- Option ROM Embedded in Phoenix BIOS
- Agreements with law enforcement agencies.
- Inside notebooks from HP, Dell, Lenovo, Toshiba, Gateway, Asus, Panasonic, and more.


#### Option ROM header:

```
000000000 55 aa 2a eb 15 43 6f 6d 70 75 54 72 61 63 65 20 | U.*..CompuTrace 000000010 56 38 30 2e 38 36 36 78 1d 00 e9 5c 01 50 43 49 | V80.866x...\.PCI 00000020 52 17 19 34 12 00 00 18 00 00 06 00 00 2a 00 00 | R..4.....*..
```



## **Basic Inner workings:**

See patent application US 2006/0272020 A1





#### **Basic Inner workings:**

PCI Option ROM

Computrace Loader Module -6kb

Agent Installation Module -6kb

Agent -10kb

**Configuration Block** 

PCI Header Reserves memory (PMM) Loads Agent Inst. Module Resize (Unload)

Installs Agent in supported OSes Supports NT/2000/XP and 9x/Me Supports FAT/FAT32 and NTFS

Agent self-installs instance
As service in OS
The Agent service once
Installed, initiates all server
Sessions (RPC over HTTP-like)



#### **Problems found:**

- Huge privacy risk (bad/no authentication)
- Anyone could activate it with enough privileges
- Anyone can change the configuration
- Anyone can de-activate it (at least in certain known cases)
- Whitelisted by AV (potentally indetectable)



## **More problems found:**

- Use of URL instead of IP (hosts redirection)
- Configuration block modification: Demo if there is time...

```
Configuration block XOR 0xB5:
00000000 b1 b7 b5 b5 35 ab b1 b4
                                 b5 f5 b4 aa b1 b5 b5 b5
00000010 b5 a5 bf 41 41 30 49 4e
                                30 30 30 30 30 95 b1 1f
                                                           ...AA0IN00000...
00000020 ee 30 86 a0 b1 8b b5 35
                                b5 ac ae 4a 4a 4a 4a
                                                           .0....5...JJJJJ
00000030 4a 4a 4a 4a 4a 4a 4a
                                4a 4a 4a 4a 4a 4a 4a
                                                           JJJJJJJJJJJJJJJJ
00000040 4a 4a 4a 4a 4a 4a af b4
                                35 ae b3 b5 b5 b5 b5
00000050 b5 a8 b7 b5 b5 f3 b3 b5 b5 b5 b5 b5 f2 b3 b5
00000060 b5 b5 b5 b5 b5 fd af 00 50 d1 35 71 17 73 65 61
                                                           ........P.5q.sea
00000070 72 63 68 2e 6e 61 6d 65 71 75 65 72 79 2e 63 6f
                                                           rch.namequery.co
                                35 b4 b4 b5 b5 b2 b3 b5
00000080 6d bf b7 b2 a5 b3 b3 ac
00000090 b5 b5 b5 b5 4a 98 b4 0d
                                98 b4 0d 9e b1 41 54 44
                                                           ....J......ATD
                                                           T..8,..9,..9,918
000000a0 54 81 b7 38 2c 80 b7 39
                                 2c 82 b2 39 2c 39 31 38
```

Stub agent: Unauthenticated BIOS code execution



#### Second Stage (AIM) loader, Stub Agent (DELL Vostro 1510 Computrace V 70.785)

```
seg000:0227
                                                                                                                                                 di, bx
                                                      ; CODE XREF: sub 27F+20lp
seg000:01CF sub 1CF
                             proc near
                                                                                                           seg000:0229
                                                                                                                                                 di, bp
seg000:01CF
                             push
                                                                                                                                                 di, 2
                                                                                                            seg000:022B
seq000:01D0
                                                                                                            seg000:022E
                                                                                                                                         add
                                                                                                                                                 di, si
seg000:01D1
                             assume es:nothing
                                                                                                            seq000:0230
seg000:01D1
                                                                                                            seg000:0231
seg000:01D4
                                      [si+6], cx
                                                                                                            seq000:0232
                                                                                                                                                 di, ax
seg000:01D7
                                                                                                            seq000:0234
                                                                                                                                                 short loc 1E5
seg000:01D9
                                      ah, 42h; 'B
                                                                                                                                                 edx, 10h
                                                                                                            seg000:0236
seg000:01DB
                                                       ; DISK -
                                                                                                            seg000:023A
seg000:01DD
                             push
                                                                                                            seg000:023A loc 23A:
                                                                                                                                                                  ; CODE XREF: sub 1CF+A61j
seg000:01DE
                                                                                                             eg000:023A
                                                                                                                                                 esi, [bx]
seg000:01DF
                                      short loc_1E2
                                                                                                           seg000:023D
seq000:01E1
                                                                                                            seg000:0241
                                                                                                                                                 short locret 1E1
seg000:01E1 locret 1E1:
                                                       ; CODE XREF: sub 1CF+1Blj
                                                                                                            seg000:0243
                                                                                                                                                 si, 9
seg000:01E1
                                                       ; sub 1CF+72↓j
                                                                                                            seg000:0246
                                                                                                                                                 si, [si+7E00h]
seq000:01E1
                                                                                                            seg000:024A
                                                                                                                                                 di, bx
seg000:01E2
                                                                                                            seg000:024C
                                                                                                                                                 di, bp
seg000:01E2
                                                                                                           seg000:024E
                                                                                                                                                 di, 2
seg000:01E2 loc 1E2:
                                                       ; CODE XREF: sub 1CF+101j
                                                                                                            seg000:0251
seg000:01E2
                                      ecx, ecx
                                                                                                            seg000:0252
                                                                                                                                                 di, 9
seg000:01E5
                                                                                                            seq000:0255
                                                                                                                                                 di, [di+100h]
seg000:01E5 loc 1E5:
                                                       ; CODE XREF: sub 1CF+2D1j
                                                                                                           seg000:0259
                                                                                                                                                 cx, 200
seq000:01E5
                                                       ; sub 1CF+331j ...
                                                                                                            seg000:025C
seg000:01E5
                                                                                                            seg000:025C loc 25C:
                                                                                                                                                                  ; CODE XREF: sub 1CF+9F1j
seg000:01E7
                                                                                                           seg000:025C
seq000:01EA
                                      short locret 1E1
                                                                                                            seg000:025D
                                                                                                                                                 dh, al
seg000:01EC
                                      ebx, ecx
                                                                                                                                                 ah, 8
                                                                                                           seq000:025F
seg000:01EF
                                     bx, 9
                                                                                                           seg000:0261
seg000:01F2
                                     bx, [bx+7E00h]
                                                                                                            seg000:0261 loc 261:
                                                                                                                                                                  ; CODE XREF: sub 1CF+9Clj
                                     eax, byte ptr [bx]
зеq000:01F6
                                                                                                           seg000:0261
                                                                                                                                                 dx, 1
seg000:01FA
                                                                                                           seq000:0263
                                                                                                                                                 short loc 269
seg000:01FC
                                      short loc 1E5
                                                                                                                                                 dx, 1021h
                                                                                                           seg000:0265
seg000:01FE
                                                                                                            seg000:0269
seg000:01FE loc 1FE:
                                                                                                           seg000:0269 loc 269:
                                                                                                                                                                  ; CODE XREF: sub 1CF+94Tj
                                                       ; DATA XREF: sub 27F+3010
seg000:01FE
                                                                                                           seg000:0269
seq000:01FE
                                      eax, [bx+4]
                                                                                                                                                 short loc 261
                                                                                                            seg000:026B
seg000:0202
                                                                                                            seg000:026D
                                                                                                                                         stosb
seg000:0204
                                      ecx, [ebx+eax*4]
                                                                                                            seq000:026E
                                                                                                                                                 loc 250
seg000:0209
                                      short loc 1E5
                                                                                                            seg000:0270
                                                                                                                                                 bx, 4
                                      eax, [ebx+eax*4+4]
eg000:020B
                                                                                                            seg000:0273
                                                                                                                                                 bx, bp
seg000:0211
                                      short loc 1E5
                                                                                                            seq000:0275
                                                                                                                                                 short loc 23A
seg000:0213
                                      dx, [bx+2]
                                                                                                                                                 eax, edx, 10h
                                                                                                            seg000:0277
                                                                                                                                         shld
seg000:0216
                                     ebp, byte ptr [bx+1]
                                                                                                           seg000:027C
                                                                                                                                                 ax, dx
seq000:021B
                                      si, bp
                                                                                                           seq000:027E
seg000:021D
                             lea
                                     bp, [ebx+ebp*4+4]
                                                                                                           seg000:027E sub 1CF
                                                                                                                                         endp
seg000:0222
                                     bx, [ebx+eax*4-4]
```



## **Detecting the Rootkit Agent**

- A single file to look for:
  - system32\rpcnet.exe (Normal Agent)
  - system32\rpcnetp.exe (BIOS Persistent Agent)
- A service called "Remote Procedure Call (RPC) Net" with no description
- Outgoing connections to search.namequery.com (209.53.113.223)
- Our Computrace Option Rom Dumper tool




# **Deactivating:**

- Easiest way: hosts file redirection
- Modifying BIOS (only unsigned BIOS!)
- Modifying configuration block (Registry, hard-disk, etc.)
- Modifying nvram, then full HD Wipe.



#### The Past:

- US 6,300,863 B1 Pat. Figure 8A
- Filed Mar 24 1998, Absolute Corporation
- Agent inside modem Option ROM
- Support for DOS Backdooring



See "Implementing and Detecting a PCI Rootkit", Heasman, BlackHat 2007



#### The Future:

- Phoenix Failsafe:
  - Inside SMM, sounds familiar?
  - Always-on OS-independent, Wifi and GPS tracking
  - It has "safe" in the name instead of "trace"
- Intel Anti-theft technology:
  - vPro technology
  - Using AMT secondary processor
  - Works even with the notebook turned off!
- Other security aplications residing in BIOS

Strong authentication: "Trust us, is for your own protection".



## This is only the begginning

- More research is needed in this area!
- CoreBoot (LinuxBIOS) project, is computrace-free
- Questions?
- Thanks! Now if you'll just look into the light:

